
How to Remove the Filters



1. First, remove the magnetic filter strip on both sides.



2. Pull on one of the black tabs to remove the pre-filter.





3. Slide out the MERV-10 filter (the MERV-10 filter comes standard on the unit but you may also have a carbon or HEPA filter).



